


DEVICE HOW TO ▾ LEARN ABOUT ▾ SHOP



Affiliate Programme Blog Forums

# How to reinstall Windows on your GPD Pocket





Last updated: 20 November 2021

Q ex.: Installation


Home ▶ Hardware

⌚ Estimated reading time: 1 min

**NOTE: Performing this installation will erase the storage and reinstall Windows from scratch on your GPD Pocket, so please ensure you have backed up any important files before proceeding!**

The GPD Pocket should be fully charged before starting this procedure. You will need a 8GB or larger USB Memory Stick to copy the files onto.

Download the GPD Pocket firmware from: <https://1drv.ms/u/s!AIRdlhGu3fjih0I1SFpg2oftC4LS>



Connect your 8GB or larger USB Memory Stick to your PC. In Explorer, Right Click on the USB Memory Stick and choose the **Format** option. Change the File System to **NTFS**, and the Volume Label to **WINPE** as shown below or the firmware flash will not work.





Connect the USB Memory Stick to the USB 3.0 port on the side of the GPD Pocket.

Switch the GPD Pocket on, immediately hold the **Fn** button and repeatedly tap the **F7** button until the Boot Manager screen appears. **NOTE: The display will be rotated 90 degrees and is perfectly normal in this process.**



Using the **Up/Down** buttons on the GPD Pocket keyboard, navigate to your USB Memory Stick and then press the **Enter** button to choose it.


The firmware reflash will now proceed and is automated – you can now leave it until you see the Windows desktop again. The process will take around 20 to 30 minutes, do not switch the device off or press any buttons during this time.



Once you are on the desktop, press the **Cancel** button on the Window that appears, **do NOT press OK!**



You can now double click on the **Cleanup Test** icon on the desktop to run a clean up.



The GPD will now perform some cleanup tasks, let them complete, and afterwards the device will switch off. Once this is done, you can now switch the device back on and it will boot to the Windows first use screen, it is now ready to use.

Tags: GPD

Was this article helpful?

😊 Like 0

☹ Dislike 0

## Continue reading

« Previous: [Best software for your GPD Pocket](#)

Next: [Changing The Launcher On A Go v3](#) »

< PREVIOUS ARTICLE



**LibreELEC Basics**

NEXT ARTICLE >

**How to Clear App Data on Android 6 & 7 devices**



# What do you think?

0 Responses



Upvote



Funny



Love



Surprised



Angry



Sad

0 Comments

Login ▼

G

Start the discussion...

LOG IN WITH

OR SIGN UP WITH DISQUS

Name



Share

Best Newest Oldest

Be the first to comment.

Subscribe

Privacy






Do Not Sell My Data

## Recent articles

- Getting Started with the AYANEO SLIDE
- Getting Started with the AYN Odin 2 Super Dock
- How to Fix the Retroid Pocket Boot Loop
- Getting Started With The Retroid Pocket 4
- Getting Started with the GuliKit 7-in-1 Docking Station

## Recent topics



-  Accessories
-  Android
-  Android Gaming Handhelds
-  Android TV Box
-  Gamepads

### Learn More About

- Mini PCs .....
- Windows Gaming Handhelds .....
- Ultrabooks .....
- Android Gaming Handhelds .....
- Retro Gaming Handhelds .....
- Retro Gaming Consoles .....
- Android TV Box .....

### Buy Now

- Mini Computers .....
- Gaming Handhelds .....
- Retro Gaming Handhelds .....
- Ultrabooks .....
- Android Gadgets .....



©DroiX© Copyright Entertainment Gadgets LTD 2013 - 2024 All rights reserved.

- English (USA) (English)
- English (United Kingdom)
- Deutsch (German)
- Français (French)
- Italiano (Italian)
- Español (Spanish)
- Dansk (Danish)
- Suomi (Finnish)
- Polski (Polish)
- Português (Portuguese, Portugal)

Svenska (Swedish)

Spanish (Mexico)

Português (Portuguese, Brazil)

Čeština (Czech)

Norsk bokmål (Norwegian Bokmål)